


For short implant placement, implant major diameter needs to be \leq the bur (average diameter) at the 8mm laser mark. Please refer to page 16 in the Instructions for Use Manual.

In Ridge Expansion cases, please oversize your osteotomy and make sure that the crest diameter is equal to or larger than the implant major diameter.

Use Densah Burs in full-step increments for Sinus Lift cases. Example: 2.0mm, 3.0mm, 4.0mm, 5.0mm



Use large block display to compare Bur identification system when using the schematic below for proper Bur usage

● VT5 Set ○ VT8 Set ● VS8 Set

| Densifying Mode CCW (800-1500) RPMs / Cutting Mode CW (800-1500) RPMs | | | | | | | | | | | | | | | | | |
|---|---------|----------|---|---------------|---------------|---------------|---------------|---------------------------|-------|--------------|---------------|---------------|---------------|--------------|---------------|-------|---------------------------|
| Adin | | | Close Fit, Touareg-S, Touareg-OS - One | | | | | | | | | | | | | | |
| | | | Soft Bone | | | | | Hard Bone (Mandible) | | | | | | | | | |
| | | | In densifying mode make sure your osteotomy is 1.0 mm deeper than the actual implant final length. In extreme hard bone, utilize DAC (Densify After Cut) Protocol. Find protocol in IFU. | | | | | | | | | | | | | | |
| Geometry | Major Ø | Minor Ø | Pilot | Bur 1 | Bur 2 | Bur 3 | Bur 4 | Densah® Bur Block Display | Pilot | Bur 1 | Bur 2 | Bur 3 | Bur 4 | Bur 5 | Bur 6 | Bur 7 | Densah® Bur Block Display |
| Taper | 2.75 | 2.00 | Pilot | VT1525* (2.0) | — | — | — | | Pilot | VT1525 (2.0) | VT1828* (2.3) | — | — | — | — | — | |
| Taper | 3.00 | 2.2 -2.3 | Pilot | VT1828* (2.3) | — | — | — | | Pilot | VT1828 (2.3) | VS2228* (2.5) | — | — | — | — | — | |
| Taper | 3.50 | 2.5-2.9 | Pilot | VT1525 (2.0) | VS2228* (2.5) | — | — | | Pilot | VT1525 (2.0) | VT1828 (2.3) | VT2535* (3.0) | — | — | — | — | |
| Taper | 3.60 | 2.90 | Pilot | VT1525 (2.0) | VT2535* (3.0) | — | — | | Pilot | VT1525 (2.0) | VT1828 (2.3) | VT2535 (3.0) | VT2838* (3.3) | — | — | — | |
| Taper | 3.75 | 3.10 | Pilot | VT1525 (2.0) | VT2535* (3.0) | — | — | | Pilot | VT1525 (2.0) | VT1828 (2.3) | VT2535 (3.0) | VT2838* (3.3) | — | — | — | |
| Taper | 4.20 | 3.30 | Pilot | VT1828 (2.3) | VT2838* (3.3) | — | — | | Pilot | VT1828 (2.3) | VT2535 (3.0) | VT2838 (3.3) | VS3238* (3.5) | — | — | — | |
| Taper | 4.30 | 2.90 | Pilot | VT1828 (2.3) | VT2838* (3.3) | — | — | | Pilot | VT1828 (2.3) | VT2535 (3.0) | VT2838 (3.3) | VS3238* (3.5) | — | — | — | |
| Taper | 5.00 | 3.7-4.1 | Pilot | VT1525 (2.0) | VT2535 (3.0) | VT3545* (4.0) | — | | Pilot | VT1828 (2.3) | VT2535 (3.0) | VT2838 (3.3) | VT3545 (4.0) | VT3848 (4.3) | — | — | |
| Taper | 6.00 | 5.10 | Pilot | VT1828 (2.3) | VT2838 (3.3) | VT3848 (4.3) | VT4555* (5.0) | | Pilot | VT1828 (2.3) | VT2535 (3.0) | VT2838 (3.3) | VT3545 (4.0) | VT3848 (4.3) | VT4858* (5.3) | — | |


*Denotes implant placement.

*Clinician experience and judgment should be used in conjunction with the Densifying Reference Guide recommendation and suggested use protocols.

For short implant placement, implant major diameter needs to be \leq the bur (average diameter) at the 8mm laser mark. Please refer to page 16 in the Instructions for Use Manual.

In Ridge Expansion cases, please oversize your osteotomy and make sure that the crest diameter is equal to or larger than the implant major diameter.

Use Densah Burs in full-step increments for Sinus Lift cases. Example: 2.0mm, 3.0mm, 4.0mm, 5.0mm



Use large block display to compare Bur identification system when using the schematic below for proper Bur usage

● VT5 Set ○ VT8 Set ● VS8 Set

| Densifying Mode CCW (800-1500) RPMs / Cutting Mode CW (800-1500) RPMs | | | | | | | | | | | | | | | | | |
|---|---------|---------|--|--------------|---------------|---------------|---------------|---------------------------|----------------------|--------------|--------------|---------------|---------------|---------------|---------------|-------|---------------------------|
| Adin | | | Swell | | | | | | | | | | | | | | |
| | | | Soft Bone | | | | | | Hard Bone (Mandible) | | | | | | | | |
| | | | In densifying mode make sure your osteotomy is 1.0 mm deeper than the actual implant final length. In extreme hard bone, utilize DAC (Densify After Cut) Protocol. Find protocol in IFU. | | | | | | | | | | | | | | |
| Geometry | Major Ø | Minor Ø | Pilot | Bur 1 | Bur 2 | Bur 3 | Bur 4 | Densah® Bur Block Display | Pilot | Bur 1 | Bur 2 | Bur 3 | Bur 4 | Bur 5 | Bur 6 | Bur 7 | Densah® Bur Block Display |
| Straight | 3.30 | 2.70 | Pilot | VT1828 (2.3) | VS2228* (2.5) | — | — | | Pilot | VT1828 (2.3) | VS2228 (2.5) | VT2535* (3.0) | — | — | — | — | |
| Straight | 3.73 | 2.70 | Pilot | VT1525 (2.0) | VT2535* (3.0) | — | — | | Pilot | VT1525 (2.0) | VT1828 (2.3) | VT2535* (3.0) | — | — | — | — | |
| Straight | 4.20 | 2.70 | Pilot | VT1828 (2.3) | VT2535* (3.0) | — | — | | Pilot | VT1828 (2.3) | VT2535 (3.0) | VT2838 (3.3) | VS3238* (3.5) | — | — | — | |
| Straight | 5.00 | 3.50 | Pilot | VT1828 (2.3) | VT2838 (3.3) | VT3848* (4.3) | — | | Pilot | VT1828 (2.3) | VT2535 (3.0) | VT2838 (3.3) | VT3545 (4.0) | VT3848* (4.3) | — | — | |
| Straight | 6.00 | 4.50 | Pilot | VT1828 (2.3) | VT2838 (3.3) | VT3848 (4.3) | VT4858* (5.3) | | Pilot | VT1828 (2.3) | VT2535 (3.0) | VT2838 (3.3) | VT3545 (4.0) | VT3848 (4.3) | VT4858* (5.3) | — | |

*Denotes implant placement.

*Clinician experience and judgment should be used in conjunction with the Densifying Reference Guide recommendation and suggested use protocols.